If you plan on adding a decal to the liner please note that the decal must go on the smooth side of the liner. The decal will not adhere to the textured side. Put the spray adhesive on the textured side and the underside of the hood.

To install this liner I recommend 3M spray adhesive #80. Its a high temp adhesive made for this type of material. Do NOT use general adhesive sprays or sprays designed for carpet. On my own car, 3M # 80 has held up for several years.

3M spray adhesive #80. Is available from www.mcmastercarr.com and Home Depot

McMaster Carr product ID 7610A16.

On some models, it is easier to remove the hood to install it.

The hood liner is resistant to water, oils, heat etc, but its not indestructible. If you pull it too hard or gouge it with a tool it will tear. Handle it carefully.

- It's pre-cut to fit without trimming but if you stretch it don't worry, you can trim it off at the bottom.
- With the hood on a smooth flat surface and protected from scratches dry fit it to get a feel for the material and see how it lines up.
- Mask off areas to protect from over spray.
- Follow the instructions for the adhesive you're using.
- Spray the hood with adhesive.
- Cover the area you just sprayed with wax paper. The kind you get at a grocery store. The wax paper should be bigger than the hood liner so you can grab the ends.
- Spray the hood liner with adhesive.
- Set the liner into place on top of the wax paper.
- Line it up and tuck in the sides and corners.
- When it's lined, up pull out the wax paper and press the liner into place.

If you have a helper, apply adhesive to the liner and hood. Hold the liner over the hood at all four corners and line it up. When it's lined up, drop it into place. Smooth it from the center out, tuck it under the edge and trim off any excess .If you get any air bubbles when you drop it and they won't move to the end when you smooth it, poke it with a pin to let the air out.