



## Midget/Sprite Instructions

Thank you for purchasing the “WIND BLOCKER” shield. We are sure you will enjoy the comfortable top down cruising that the shield provides. Installation is quite simple too! First remove the 3 bolts or screws on one side that hold the pivot plate for your top’s frame. Match up the supplied socket with the plate’s perimeter and bolt pattern and slip it underneath the plate while reinstalling the bolts or screws. Do the same for the other side as well and make sure the bolts or screws are tight. Install the end brackets by sliding the tabs, without the holes, into the ends of the “Wind Blocker” crossbar. Remove the thumbscrews and slide the tabs, with the threaded holes, into the tonneau bar sockets, which are now bolted beneath the top mounting plates on your Midget.

If you have the top boot on, you may need to pull it aside slightly to allow the brackets to fit.

Next thread the thumbscrews into the brackets through the side holes in the sockets, after they are seated in the tonneau sockets. You will probably need to adjust the brackets a little in order to get the threaded holes to line up with the holes in the tonneau sockets. Tighten the screws and you are ready to enjoy cruising.

**NOTE: Using the “WIND BLOCKER” without securing the thumbscrews may result in it coming loose. Use of the shield without securing it is done at your risk!**