



“WIND BLOCKER” TR6 Instructions

Thank you for purchasing the “WIND BLOCKER” for TR6. You will now be able to enjoy hours of top down cruising without being battered by the wind. Installation is very simple.

The two mounting brackets enclosed are marked on their back sides with left and right. These are fitted beneath the pivot plate for your soft top. The left one goes on the driver’s side. Unscrew the two screws for the left side top pivot plate and slide the left mounting bracket beneath the top pivot plate and match up the two screw holes with the holes in the mounting plate. Using the longer allen drive screws provided, insert screws through the pivot plate and mounting bracket and screw them in finger tight. Do the same procedure on the right side pivot plate.

The mounting brackets have slightly larger holes to allow for final adjustment. Bring each mounting bracket up as high as it will go in the rear and tighten all four screws.

The small “L” brackets slide into the extrusion which holds the shield and the two allen head cap screws thread into the threaded holes at the rear of each mounting bracket. Tighten both allen screws and you are ready to cruise in comfort.

If you need to raise your top, simply unscrew the two allen screws and pull the top frame up but before securing it reinstall the shield and it can remain out of the way beneath your top and not take up valuable trunk space