



Frogeye/Bugeye Instructions

Thank you for purchasing the "WIND BLOCKER" shield. We are sure you will enjoy the comfortable top down cruising that the shield provides. Installation is quite simple too!

Install the body mount brackets by using the two screws in the rear corner of the cockpit which hold the aluminum trim onto the body. The brackets mount underneath the rear scuttle and are secured thru the two holes in the brackets which are 5 1/8 inches apart. Using the nuts and suitable washers which are on the existing screws securely attach the brackets. The brackets mount as left and right with the horizontal tab with the 1/4-20 tapped hole towards the outside of the car and projecting forward into the cockpit. Once properly mounted you will only see the two tabs with the tapped hole projecting in each corner of the cockpit.

The two "Z" angled brackets slide into the crossbar of the shield and are secured to the two tabs on the body mount brackets using the 1/4-20 thumbscrews provided.

You may need to adjust the angle of the tabs slightly to achieve an upright position for the shield. They can be bent after they are secured to the body using the "Z" bracket.

When storing the shield, use the storage bag available from LBC to keep it from being scratched.

The Wind Blocker makes those long or chilly top down drives so much more enjoyable as it cuts off the blast of air coming up over your windshield.