



TR7 & TR8 Wind Blocker Instructions

Thank you for purchasing the “WIND BLOCKER” for your TR7 or TR8. You will now be able to enjoy hours of top down cruising without being battered by the wind. Installation is very simple.

The two mounting brackets enclosed are marked with left and right. These are fitted beneath the inertia reel mountings using the existing bolts. The left one goes on the driver’s side. Unbolt the seat belt inertia reel, slide the bracket under it. There is an alignment tab forward of the bolt to keep the reels from spinning. This tab goes through a hole in the bracket. Replace the bolt, but don’t tighten until the whole assembly is in place.

The small “L” brackets slide into the extrusion which holds the shield and the two thumbscrews thread into the threaded holes at the front of each mounting bracket. Tighten both thumbscrews, **tighten the inertia reel bolts**, and you are ready to cruise in comfort.

Each thumbscrew has a plastic retaining ring on it. Leave it on to avoid losing the thumbscrews when storing the Wind Blocker.

Simply peel the protective layer from both sides of the shield.